

# Operating instructions

## ZF Electronic Control Unit ERM

6057 758 101b

Subject to alterations in design

Copyright by ZF

The present documentation is protected by copyright.  
Any kind of reproduction or dissemination in whatever  
form that does not exclusively correspond to documen-  
tation objectives will be prosecuted if no prior approval by  
ZF Friedrichshafen AG was granted.

Printed in Germany

ZF Friedrichshafen AG, MC-C / 2001-03

Issue: 2005-02

Companies repairing ZF units are responsible for their own work safety.

**To avoid injury to personnel and damage to products, all safety regulations and legal requirements which apply to repair and maintenance work must be adhered to. Before starting work, mechanics must familiarize themselves with these regulations.**

**Personnel required to carry out repairs on ZF products must receive appropriate training in advance. It is the responsibility of each company to ensure that their repair staff is properly trained.**

The following safety instructions appear in this manual:

### **NOTE**

Refers to special processes, techniques, data, use of auxiliary equipment, etc.

### **CAUTION**

**This is used when incorrect, unprofessional working practices could damage the product.**



### **DANGER**

**This is used when lack of care could lead to personal injury or death.**

---

Read this manual carefully before starting any tests or repair work.

### **CAUTION**

**Pictures, drawings and components do not always represent the original object, but are used to illustrate working procedures.**

**Pictures, drawings and components are not to scale. Conclusions about size and weight should not be drawn (even within a complete illustration). Always follow the working steps as described in the text.**

**After completion of repair work and testing, skilled staff must satisfy themselves that the product is functioning correctly.**

---

<b>1</b>	<b>Technical data</b>	6	<b>3.4</b>	Operating mode “controlled with $\emptyset$ calculation”	30
1.1	Technical data, installation dimensions	6	3.4.1	Function diagram	30
1.2	Circuit board removal and installation	8	3.4.2	Pin assignment	31
1.3	Circuit board configuration	10	3.4.3	Technical instructions	32
1.4	Pin assignment	12	3.4.4	Startup	33
1.5	Summary of pin assignment	14	<b>3.5</b>	Operating mode “closed-loop control”	34
<b>2</b>	<b>Description</b>	16	3.5.1	Function diagram	34
2.1	General configuration	16	3.5.2	Pin assignment	35
2.2	Coding clutch / brake	18	3.5.3	Technical instructions	36
2.3	Controller for transfer function	19	3.5.4	Startup	36
<b>3</b>	<b>Operating modes</b>	20	<b>3.6</b>	Additional functions max-power / zero-power	37
3.1	Operating mode “open loop (current)”	20	<b>4</b>	<b>Identification and causes of failure /</b>	
3.1.1	Function diagram	20		<b>corrective action</b>	38
3.1.2	Pin assignment	21			
3.1.3	Technical instructions	22			
3.1.4	Startup	22			
3.2	Operating mode “open loop (torque)”	23			
3.2.1	Function diagram	23			
3.2.2	Pin assignment	24			
3.2.3	Technical instructions	25			
3.2.4	Startup	25			
3.3	Operating mode “controlled with $\emptyset$ sensing”	26			
3.3.1	Function diagram	26			
3.3.2	Pin assignment	27			
3.3.3	Technical instructions	28			
3.3.4	Startup	28			

## 1 Technical data

### 1.1 Technical data, installation dimensions

Nominal direct voltage for ZF hysteresis clutches and brakes at nominal torque and a coil temperature of 120 °C:

30 V DC

Permissible residual ripple:

1.5 V

Operating voltage range:

24 V to 36 V DC

Open circuit power consumption:

< 150 mA

Maximum current input:  
(depending on unit size)

2.8 A

Fuse:

fine-wire fuse 4A  
medium time-lag fuse

Voltage output:

10 V = +/- 0.8 V  
20 mA  
( $R_{a \min} = 500 \Omega$ )

Frequency input:

input resistance  
 $R_E \geq 3.3 \text{ k}\Omega$

Switching threshold “low” to “high” > 11.5 V DC

Switching threshold “high” to “low” < 4.0 V DC

Ambient temperature: 0 to +50 °C

Storage temperature: -30 to +70 °C

Humidity class: DIN IEC 68, part 2-30

Safety class according to DIN 40 050: IP 30


Rack: 19” 7 TE plug-in module

Connection: 18-pin pull-off screw-type terminal (within the scope of supply)

Weight: 0.6 kg

#### NOTE

The screw-type terminal block is not suitable for bus assembly. Make sure that connecting cables are long enough or that the screw-type terminal block on the rear of the assembly rack is accessible.

**Installation dimensions**

## 1.2 Circuit board removal and installation

### Removal:

1. Switch off operating voltage.

### CAUTION

**If the operating voltage is not switched off, product and system can be damaged.**

2. Remove terminal strip (2) from plug connector (3).
3. Remove screws (1 + 4).
4. Carefully pull board out of the rack without tilting.

### Installation:

1. Carefully insert board into rack, guiding slot without tilting.
2. Tighten screws (1 + 4) so that the cooling attachment on the board contacts the metal rack and thus ensures optimum heat dissipation.

### NOTE

Do not exceed permissible tightening torque to avoid board damage.

3. Make sure that operating voltage is switched off.

### CAUTION


**If the operating voltage is not switched off, product and system can be damaged.**

4. Introduce terminal strip (2) into plug connector (3).

### CAUTION

**Contacts must not be damaged, otherwise perfect functioning of the system is not ensured.**







015239

### 1.3 Circuit board configuration

Designation	Function
LED (1) "Power"	Supply voltage is applied and ERM program is ready.
LED (2) "Feedb."	Closed-loop control operating mode, i.e. DIL switch position 5 and 6 = "1".
LED (3) "Ø-Contr."	<ul style="list-style-type: none"> <li>• Ø sensing operation, DIL switch position 5 = "1" and 6 = "0" or</li> <li>• Ø calculation operation, DIL switch position 5 = "0" and 6 = "1".</li> <li>• LED "Ø-Contr." flashes, if the setting procedure has not been carried out in the operating mode Ø calculation or Ø sensing.</li> </ul>
Connection for diagnostic unit	Diagnostic connector for ZF MOBiDIG tester K-cable, acc. to ISO 9141
Jumper	For function selection. e.g. feed rate interruption, emergency brake
Fuse	Fine-wire fuse 4 A, medium time-lag fuse
DIL switches	Setting of various operating modes and unit sizes
Program memory	Includes microprocessor operating program
Data memory	Contains operating parameters
Terminal strip	18-pin



1.4 Pin assignment



**NOTE**

The electronic control unit does not require the potentiometer to fulfill any particular requirements. However, mechanical requirements regarding installation need to be considered.


**Recommendations for potentiometer:**

Resistance value: 1 k $\Omega$  - 47 k $\Omega$

Type: magneto-resistive potentiometer, for voltage input nom. value also wire potentiometer can be used.

**Jumper-Position:**

Appropriate function is activated by inserting a jumper.

**NOTE**

Pos. 1 and 2 must never be connected simultaneously.

## 1.5 Summary of pin assignment

<b>PIN</b>	<b>Function</b>	<b>PIN</b>	<b>Function</b>
1	ground (-)	9	<b>voltage input, nominal value (0 to +10 V)</b> input resistance $R_i = 200 \text{ k}\Omega$ ; Input may also be supplied by external analog sources, provided the voltage refers to ground (PIN 5) and the max. value does not exceed +10 V.
2	ground (-)	10	<b>digital input "stop"</b> input resistance $4.7 \text{ k}\Omega$ ; input current 5 to 8 mA;* $U_{\text{max}}$ = operating voltage Function is maintained as long as the signal is on.
3	no assignment	11	<b>digital input "set" (push-button)</b> input resistance $4.7 \text{ k}\Omega$ ; input current 5 to 8 mA;* $U_{\text{max}}$ = operating voltage
4	no assignment	12	<b>frequency input - <math>f_n</math> (roller speed)</b> frequency 3 to 1000 Hz; input resistance $3.3 \text{ k}\Omega$ pulse $\geq 0.5 \text{ ms}$ , interpulse period $\geq 0.5 \text{ ms}$ input resistance $3.3 \text{ k}\Omega$
5	analog ground		
6	<b>current return cable (measurement input)</b> clutch / brake max. 2.55 A (depending on unit size)		
7	<b>voltage output 10 V <math>\pm</math> 0.8 V DC</b> max. load 20 mA; load impedance $R_{a \text{ min}} = 500 \Omega$		
8	<b>voltage input, actual value (0 to +10 V)</b> input resistance $R_i = 200 \text{ k}\Omega$ ; Input may also be supplied by external analog sources, provided the voltage refers to ground (PIN 5) and the max. value does not exceed +10 V.		

**PIN Function**

- 13 frequency input -  $f_v$  (feedrate)**  
 frequency 3 to 1000 Hz;  
 input resistance 3.3 k $\Omega$   
 pulse  $\geq$  0.5 ms, interpulse period  $\geq$  0.5 ms  
 input resistance 3.3 k $\Omega$
- 14 output roller speed**  
 output voltage 24 V DC;  
 max. load 50 mA;  
 max. load impedance 10 k $\Omega$ ;  
 A suppressor diode must be used with inductive load (no varistor!)  
**input current - zero**  
 load current 1 to 2 mA;\*  
 For functions consult relevant operation mode.  
 Function is maintained as long as the signal is on.
- 15 output feedrate**  
 output voltage 24 V DC;  
 max. load 50 mA;  
 max. load impedance 10 k $\Omega$ ;  
 A suppressor diode must be used with inductive load (no varistor!)  
**input current - max.**  
 load current 1 to 2 mA;\*  
 For functions consult relevant operation mode.  
 Function is maintained as long as the signal is on.

**PIN Function**

- 16 current output clutch / brake**  
 max. 2.55 A (depending on unit size)  
**NOTE: Limit for EBU 2000!**
- 17 voltage supply + 24 V to + 36 V**  
 max. current 2.8 A (depending on unit size)
- 18 voltage supply + 24 V to + 36 V**  
 max. current 2.8 A (depending on unit size)

**\* NOTE**

Gold-plated contacts are recommended for pushbutton, switch and relays.

## 2 Description

### 2.1 General configuration

The ZF electronic control unit ERM can control ZF hysteresis clutches and brakes in different operating modes, as required by the application.

The ERM is controlled by a microprocessor and features programming, operation and diagnosis interfaces.

The ERM is designed for optimum supply of the ZF hysteresis clutches ECU and the ZF hysteresis brakes EBU. Controlled operating modes with size coding are less suitable for performance optimized brake range.

The DIL switches enable the following operating modes to be set:

- **Operating mode: “open-loop control (current)”**  
This operating mode is set by the manufacturer, i.e. it is not necessary to change the DIL switch positions. Current is set and kept constant in accordance with the nominal value input.

Operating mode “open-loop control (current)”								DIL switch
1	2	3	4	5	6	7	8	as supplied

- **Operating mode “open-loop control (torque)”**

The DIL switches must be set to suit unit size (Y Y Y Y) (see page 18).

Torque is set and kept constant in accordance with the nominal value input.

Hereby, the interdependence of the nominal voltage value/torque is subject to approximate linear distribution.

Operating mode “open-loop control (torque)”								DIL switch
Y	Y	Y	Y	0	0	.	.	Unit size - coding (characteristic)

- **Operating mode “controlled with  $\emptyset$  sensing”**

The DIL switches must be set to suit unit size (Y Y Y Y) (see page 18).

Setting procedure:

- sense maximum roller  $\emptyset$
  - push set key
  - release set key
- (reference value for max.  $\emptyset$  is accepted).

#### NOTE

Data are stored in non-volatile memory; data are not erased when the supply voltage is switched off.



The reference value for the max.  $\emptyset$  is not erased when the supply voltage is switched off. It can therefore be used when the ERM is fitted, i.e. it can be stored in E<sup>2</sup>PROM. The stored reference value is deleted when another operating mode is selected (“open-loop control” or “closed loop control”).

Production speed and nominal traction may be altered even during operation.

Operating mode “controlled with $\emptyset$ sensing”								
1	2	3	4	5	6	7	8	DIL switch
Y	Y	Y	Y	1	0	.	.	Unit size - coding (characteristic)

- **Operating mode: “controlled with  $\emptyset$  calculation”**

The DIL switches must be set to suit unit size (Y Y Y Y) (see page 18).

Setting procedure:

- approach maximum roller  $\emptyset$
- push set key when production speed is reached

**NOTE**

If a frequency < 3 Hz is already reached during a setting procedure, no reference values will be transferred (LED 3 continues flashing). Frequency range 3 - 1000 Hz. Stored reference values are deleted when another operating mode is selected (“open-loop control” or “closed loop control”).

- release set key (reference values for max.  $\emptyset$  is accepted).

Production speed and nominal traction may be altered even during operation.

Operating mode “controlled with $\emptyset$ calculation”								
1	2	3	4	5	6	7	8	DIL switch
Y	Y	Y	Y	0	1	.	.	Unit size - coding (characteristic)

- **Operating mode “closed-loop control”**

The DIL switches must be set to suit unit size (Y Y Y Y) (see page 18).

PD, PI and PID are available for position-and-force closed-loop control.

The I portion can be blocked by stop input. Thus, the last controlled torque is maintained when the unit is stopped.

Operating mode “closed-loop control”								
1	2	3	4	5	6	7	8	DIL switch
Y	Y	Y	Y	1	1	0	0	PD for position control
Y	Y	Y	Y	1	1	1	0	PI for force control e.g. with mech. compensator
Y	Y	Y	Y	1	1	1	1	PI for force control e.g. with no-travel tension sensor or freely programmable
Y	Y	Y	Y	1	1	0	1	PID for position or force control

## 2.2 Coding clutch / brake

### NOTE


With DIL switches 1-4, the ERM control unit can be set to the corresponding clutch or brake.

Coding DIL switch								Type	nomi- nal current [A]	nomi- nal torque [Nm]
1	2	3	4	5	6	7	8			
1	0	0	0					EKU 0.3	0.9	0.4
0	1	0	0					EKU 1	1.3	1.0
1	1	0	0					EKU 3	1.5	3.0
0	0	1	0					EKU 10	1.8	12.0
1	0	1	0					EBU 0.1	0.4	0.15
0	1	1	0					EBU 0,3	0.75	0.4
1	1	1	0					EBU 1	1.25	1.1
0	0	0	1					EBU 3	1.25	3.3
1	0	0	1					EBU 10	1.5	12.0
0	1	0	1					EBU 30	2.2	39.0
1	0	0	1					EBU 60 G	1.5	82.0
0	1	0	1					EBU 200 G	2.2	268.0
1	1	0	1					EBU 250/1	1.1	0.6
0	0	1	1					EBU 500/3	1.4	2.5
1	0	1	1					EBU 1000/10	1.9	9.0
0	1	1	1					EBU 2000/30	2.7	26.0
0	0	1	1					EBU 500/30G	1.4	25.0
1	0	1	1					EBU 1000/100G	1.9	90.0
0	1	1	1					EBU 2000/300G	2.7	260.0
0	1	1	1					EBU 2000/600G	2.7	520.0

### 2.3 Controller for transfer function


PD for position control

Coding DIL switch							
1	2	3	4	5	6	7	8
						0	0




PI for force control  
e.g. mech. compensator

Coding DIL switch							
1	2	3	4	5	6	7	8
						1	0




PI for force control  
e.g. no-travel tension sensor

Coding DIL switch							
1	2	3	4	5	6	7	8
						1	1



PID for position or  
force control

Coding DIL switch							
1	2	3	4	5	6	7	8
						0	1




017601

3 Operating modes


3.1 Operating mode "open-loop (current)"

3.1.1 Function diagram



## 3.1.2 Pin assignment

Designation	PIN connection
Voltage supply plus 24 - 36 V	17, 18
Voltage supply ground	1, 2
Nominal traction sensor	7, 5, grinder 9
Hysteresis brake	16, 6



### 3.1.3 Technical instructions

LED: "Power" ON

Control: Current is set by the electronic system in accordance with the nominal value input.

DIL switch setting:

DIL switches							
1	2	3	4	5	6	7	8
0	0	0	0	0	0	0	0

DIL switch setting

Jumper position: Jumper position "2" (see 1.4, page 13) can activate further functions.

### 3.1.4 Startup

1. The electronic control unit is disconnected.
2. Make sure that voltage is within the range given under "1. Technical Data"! (see page 6)
3. Check polarity (plus / minus)!

#### CAUTION

**Unpermitted voltage and polarity may damage the installation!**


4. Switch off operating voltage!
5. Connect the ERM!
6. Switch on operating voltage!  
"Power" LED must light up.
7. The installation is ready for operation.

#### NOTE

Should the installation not function properly, see "4. Identification and causes of failure / corrective action" (see page 38)!


3.2 Operating mode "open-loop control (torque)"

3.2.1 Function diagram



3.2.2 Pin assignment

Designation	PIN connection
Voltage supply plus 24 - 36 V	17, 18
Voltage supply ground	1, 2
Nominal traction sensor	7, 5, grinder 9
Hysteresis brake	16, 6





### 3.2.3 Technical instructions

LED: "Power" ON

Control: Torque is set by the electronic system in accordance with the nominal value input.

DIL switch setting:

DIL switches							
1	2	3	4	5	6	7	8
				0	0	0	0
				0	0	0	0

Unit size coding clutch / brake,  
see page 18

DIL switch setting

Jumper position: Jumper position "2" (see 1.4, page 13) can activate further functions.

### 3.2.4 Startup

1. The electronic control unit is disconnected.
2. Make sure that voltage is within the range given under "1. Technical Data"! (see page 6)
3. Check polarity (plus / minus)!

#### CAUTION

**Unpermitted voltage and polarity may damage the installation!**


4. Switch off operating voltage!
5. Connect the ERM!
6. Switch on operating voltage!  
"Power" LED must light up.
7. The installation is ready for operation.

#### NOTE


Should the installation not function properly, consult "4. Identification and causes of failure / corrective action" (see page 38)!

### 3.3 Operating mode "controlled with $\emptyset$ sensing"

#### 3.3.1 Function diagram




015233



015236


Sensor zero position equals 0 V (as shown by the broken line)



017181

## 3.3.2 Pin assignment

Designation	PIN connection
Voltage supply plus 24 - 36 V	17, 18
Voltage supply ground	1, 2
∅ actual sensor	7, 5, grinder 8
Nominal traction sensor	7, 5, grinder 9
Set key	11, (17, 18)
Hysteresis brake	16, 6



### 3.3.3 Technical instructions

LED: "Power" ON  
 "Ø contr." flashes until the setting procedure is complete

DIL switch setting:

DIL switches							
1	2	3	4	5	6	7	8
				1	0	0	0
				1	0	0	0
				1	0	0	0

Controlled with Ø sensing

Unit size coding clutch / brake,  
 see page 18

DIL switch setting

Jumper position: Jumper position "2" and "3" (see 1.4, page 13) can activate further functions.

### 3.3.4 Startup

1. The electronic control unit is disconnected.
2. Make sure that voltage is within the range given under "1. Technical Data"! (see page 6)
3. Check polarity (plus / minus)!

#### CAUTION

**Unpermitted voltage and polarity may damage the installation!**

4. Switch off operating voltage!
5. Connect the ERM!
6. Switch on operating voltage!  
 "Power" LED must light up.  
 "Ø-Contr." LED must flash.

7. Setting of  $\emptyset$  nom. value potentiometer

- Voltage values  $U_{D_a}$  and  $U_{D_i}$  measured at random potentiometer setting.
- Nom. voltage  $U_{D_a \text{ nominal}}$  is calculated.

$Q = \frac{D_a}{D_i}$	$U_{D_a \text{ nominal}} = \Delta U \left( \frac{Q}{Q-1} \right)$	$\Delta U = U_{D_a} - U_{D_i}$
-----------------------	---	--------------------------------

- $U_{D_a \text{ nominal}}$  = nominal voltage outer diameter  
 $D_a$  = outer diameter  
 $D_i$  = inner diameter  
 $U_{D_a}$  = voltage outer diameter  
 $U_{D_i}$  = voltage inner diameter  
 $Q$  = diameter ratio  
 $\Delta U$  = voltage difference

- Set  $U_{D_a \text{ nominal}}$  by potentiometer.

8. Set max. roller  $\emptyset$ .

## 9. Push “set” key.

## 10. Release “set” key.

Reference  $\emptyset$  is accepted,  
 “ $\emptyset$  contr.” lights up.


## 11. The installation is ready for operation.

**NOTE**

Should the installation not function properly, consult  
 “4. Identification and causes of failure / corrective action”  
 (see page 38)!


### 3.4 Operating mode "controlled with Ø calculation"

#### 3.4.1 Function diagram



## 3.4.2 Pin assignment

Designation	PIN connection
Voltage supply plus 24 - 36 V	17, 18
Voltage supply ground	1, 2
Nominal traction sensor	7, 5, grinder 9
Friction factor	7, 5, grinder 8
Roller speed $f_n$	12
Feed rate $f_v$	13
Set key	11, (17, 18)
Hysteresis brake	16, 6



### 3.4.3 Technical instructions

LED: "Power" ON  
 Control: "Ø contr." flashes until the setting procedure is complete

Sampling rate: updating of frequency, 10 Hz (100 ms)

Detection of web tear: ERM offers output signals for roller and feed stoppage ( $f < 3$  Hz), which are evaluated and possibly identified as web tear by a machine controller.

Terminal 14: voltage if roller speed frequency  $< 3$  Hz

Terminal 15: voltage if feed rate frequency  $< 3$  Hz

see jumper position

\* *measured on PIN 17, 18.*

Compensation of friction:

With minor traction, installation friction may be relatively high compared to the brake torque needed. This must be considered when calculating the brake torque.

Determination of potentiometer voltage for the friction factor:

The friction factor is the result of the relation between friction torque and nominal torque and is expressed as voltage value and set by an additional potentiometer at terminal 8.

$$U_{\text{terminal 8}} = \frac{\text{friction torque}}{\text{nominal torque}} * 10$$



## Setting of DIL switches:

Adjustable filter constant	Filter time	7	8
New condition	0.5 sec	0	0
	2.5 sec	0	1
	1.5 sec	1	0
	0.2 sec	1	1

DIL switches							
1	2	3	4	5	6	7	8
Filter constant				0	1		
Controlled with Ø calculation				0	1		
Unit size coding clutch / brake, see page 18				0	1		
<b>DIL switch setting</b>				0	1		

Jumper position: Jumper position “1” or “2” (see 1.4, page 13) can activate further functions.

### 3.4.4 Startup

1. The electronic control unit is disconnected.
2. Make sure that voltage is within the range given under “1. Technical Data”! (see page 6)

3. Check polarity (plus / minus)!

#### CAUTION

**Unpermitted voltage and polarity may damage the installation!**


4. Switch off operating voltage!
5. Connect the ERM!
6. Switch on operating voltage!  
“Power” LED must light up.  
“Ø contr.” must flash.
7. Set max. roller speed Ø and production speed (> 3 Hz).
8. Push “set” key.
9. Release “set” key.  
Reference Ø is accepted,  
“Ø contr.” lights up.
10. Installation is ready for operation.

#### NOTE

Should the installation not function properly, consult “4. Identification and causes of failure / corrective action” (see page 38)!


3.5 Operating mode "closed-loop control"

3.5.1 Function diagram



## 3.5.2 Pin assignment

Designation	PIN connection
Voltage supply plus 24 - 36 V	17, 18
Voltage supply ground	1, 2
Actual traction sensor	7, 5, grinder 8
Nominal traction sensor	7, 5, grinder 9
Stop key	10, (17, 18)
Hysteresis brake	16, 6



### 3.5.3 Technical instructions

LED: "Power" ON  
"Feedb." ON

Stopping the installation: Stop contact blocks I portion (not necessary for PD position control).

Sampling rate: 100 Hz (10 ms)

DIL switch setting:

DIL switches							
1	2	3	4	5	6	7	8
				1	1		
				1	1		
				1	1		
				1	1		

Operating mode "closed-loop control"

Unit size coding clutch / brake,  
see page 18

Controller transfer function, see page 19

DIL switch setting

Jumper position: Jumper positions "2" and "3" (see 1.4, page 13) can activate further functions.

### 3.5.4 Startup

1. The electronic control unit is disconnected.
2. Make sure that voltage is within the range given under "1. Technical Data"! (see page 6)
3. Check polarity (plus / minus)!

**CAUTION**  
**Unpermitted voltage and polarity may damage the installation!**

4. Switch off operating voltage!
5. Connect the ERM!
6. Switch on operating voltage!  
"Power" LED and "Feedb." LED must light up.
7. The installation is ready for operation.

**NOTE**  
Should the installation not function properly, consult "4. Identification and causes of failure / corrective action" (see page 38)!

### 3.6 Additional functions max-power / zero-power ( $I_{\max}$ / $I_{\min}$ )

Clutch power flow can be influenced irrespective of operating mode. Zero or max. power for ERM possible (depends on size of unit connected). Optional limitation of max. power by MobiDig 200 program.

#### Application / Use

- Max-power e.g. for emergency stop
- Zero-power e.g. for start-up

#### Activation of additional functions

**Jumper** on ERM board must be in **Pos. 2**. **Pos. 1** must **not** be connected!

(cf. 1.4 Jumper position).

- **Input** for **max-power function: Pin 15**
- **Input** for **min-power function: Pin 14**
- **Ground: Pin 1** or **2**

Each function remains **active** as long a signal is present on input (**low level**, cf. 1.1 Technical data).

#### 4 Identification and causes of failure / corrective action

Failure identification	Causes	Corrective action
LED Ø contr. flashes (operating mode "controlled with Ø sensing")		➤ Repeat setting procedure (see page 28)
LED Ø contr. flashes (operating mode "controlled with Ø calculation")		➤ Repeat setting procedure (see page 33)
"Power" LED does not light up	No operating voltage or too low	➤ Check operating voltage
	ERM fuse is defective	➤ Replace defective fuse
	Program does not run correctly	➤ Consult ZF
All 3 LED lights will flash (sequentially)	Operating voltage too low or too high	➤ Check operating voltage
	Reference voltage too low	➤ Check load resistance
	Short-circuit or interruption at current output, or coil is bridged	➤ Correct short-circuit / interruption
	Missing size	➤ see operating mode, setting of DIL switches (see page 18)